

Ricmotech GTPro3 Bracket for Simagic HPR Installation Guide

This product fits the GTPro3 pedals



Tools Needed:

1. 1.5mm Allen Wrench (Hex Key)
2. 2mm Allen Wrench (Hex Key)
3. 4mm Allen Wrench (Hex Key)

Installation:



1. Begin by removing the 4 screws holding the end plate opposite from the cable side using the 1.5mm Allen wrench (hex key). You can store the 4 screws in a safe place. They won't be needed anymore.



2. Keeping the original red plate in place and screw in tightly the Ricmotech metal bracket on top of it with the provided M2.5 socket head cap screws using the 2mm Allen wrench (hex key).



3. Remove the top screw from the pedal plate using the 4mm Allen wrench (hex key). You can store the screw in a safe place.



4. Screw in firmly the HPR assembly with the provided 9/16 button cap screw using the 4mm Allen wrench (hex key).

Need Help?

If you run into any problems during the installation of the Ricmotech GTPro3 Bracket for Simagic HPR please contact us directly at tech support at (305) 417-9241 or via email at support@ricmotech.com. Due to constant improvements to our products, the product you receive may vary slightly from the product shown in the illustrations.

Copyright 2024, Ricmotech LLC. Simagic HPR is the trademark of the Simagic® corporation and the terms are used for reference purposes only. Ricmotech and GTPro3 Bracket for Simagic HPR kit are not affiliated with Simagic® Corporation.