



## RealGear RACEpro H22 Switch Layout Diagram

A	A	B	B	B	B [Program Mode]
F  Brake Bias		E  Recommended for Volume Level and Radio Channels	Dv	Dv	Dv
		E  Recommended for View Adjustments (FOV, Height, Seat, Etc.)	Dh	Dh	Dh