


## Fixing SimCommander after a Windows Update


Typically after a major Windows update and occasionally a routine update that results in the audio devices on the PC getting reset. This causes a setting in SimCommander to be reverted to “blank”. To correct this follow the steps below.



Click Control Center to open the control center.



Click SimVibe Chassis (select the words, but do not click on the checkbox).



The selection for the Sound Card will likely be blank. Select the appropriate sound card.

The Sound card for Ricmotech PCs is typically the Asus Xonar DGX (Speakers).

Close the Control Center and try start the game through SimCommander once again.